



TC OFFSET ADJUST:

With V_{in} shorted to Analog Ground and the hold switch closed adjust TC Cal. to 0V. Usually a one time adjustment.

POST AMPLIFIER OFFSET ADJUST:

With the reset switch closed adjust V_{out} to 0V. Usually a one time adjustment.

INTEGRATOR OFFSET ADJUST:

With V_{in} shorted to Analog Ground and the hold switch closed adjust V_{out} for zero integration (no change). 1 μ V/Sec. is attainable.

This adjustment is usually necessary when the TC has been changed.

TC ADJUST:

Example Results w/ Different TC values:

TC	Integration Time (sec.)	V_{in}	V_{out}
10	10	1	1
10	100	1	10
10	100	0.1	1
1	10	1	10
1	10	0.1	1
0.1	10	0.1	10
0.1	10	0.01	1

RDM-Apps

TITLE: UI10F Block Diagram with Notes

Document Number:

8546B

REV:
B

Date: 5/04/2006 09:46:39a

Sheet: 1/1